

SERVICE INSTRUCTIONS

www.keatingofchicago.com

KEATING
OF CHICAGO, INC. ®

1-800-KEATING

REPLACEMENT OF WING TURBULATOR for GAS FRYER PART # 060357

Removal & Installation:

1. Disconnect the gas and electrical supply.
2. Remove the burners and gaskets, and pull radiants out of tubes.

10"x11" and 14" Fryers:

1. Insert new wing turbulator into the tube with 45-degree bend in first, and pointing up.
2. Push turbulator in until front hook catches on bottom edge of pot tube.
The turbulator is now in place.

18" & Larger Fryers:

1. Insert new turbulator with the 45-degree bend in first and pointing up.
 2. Push turbulator all the way to back of the tube so the 45-degree bend goes past rear heat shield.
 3. Pull turbulator towards front until the bend catches the heat shield edge.
The turbulator is now in place.
3. Reinstall front gaskets and burners, then re-assemble fryer. Test fryer to insure proper operation.

