



SERVICE INSTRUCTIONS

1-800-KEATING • keatingofchicago.com

FAT MELT CONTROL REPLACEMENT INSTRUCTIONS

PART# 037470

1. Remove old Fat Melt Control. Make note of wire numbers and locations.
2. Replace with new Fat Melt Control. This part is a direct replacement for old Fat Melt.