



# SERVICE INSTRUCTIONS

1-800-KEATING • keatingofchicago.com

## INSTALLATION INSTRUCTIONS FOR CENTRAL MOTOR RESET MECHANISM (Pre 2000 Series)

1. Looking from front of unit, loosen the two bolts on the right side of motor mount.
2. Align slots on reset mechanism mounting bracket with loosened bolts and slide mounting bracket under bolt heads but on top of base plate of motor.
3. Push reset mechanism guide block tight against motor base plate and retighten bolts while holding in place.
4. Pull rod to check alignment with motor reset button.

