

SERVICE INSTRUCTIONS

www.keatingofchicago.com

KEATING
OF CHICAGO, INC.®

1-800-KEATING

REMOVAL AND REPLACEMENT OF ELECTRIC GRIDDLE ELEMENTS

REMOVAL:

1. Disconnect electric power source.
2. Remove lower heat shield by removing two screws and tilting it toward you until it drops from control panel.
3. Remove control panel by removing four screws and support it to prevent damage to wiring or other components.
4. Remove upper heat shield by removing screws holding it in place.
5. Locate element hold down brackets surrounding thermostat bulb and loosen nuts enough to slide bulb out.

NOTE: FOR ELEMENT NEXT TO GREASE TROUGH, SLIDE BULB TOWARD REAR OF GRIDDLE TO REMOVE IT.

6. Remove element by unscrewing all nuts and carefully lowering hold down brackets, element pan, insulation board, heat dispersion plate and element.

REPLACEMENT:

1. Raise new element along with heat dispersion plate, insulation board, element pan and hold down brackets and fasten in place with nuts, washers and lock washers. Do not tighten nuts for bracket which holds thermostat bulb.
2. Slide thermostat bulb into holder under heating element. Slide fabric sleeve to where bulb joins capillary and tighten element hold down nuts.
3. Replace upper heat shield and fasten with screws.
4. Replace control panel with four screws.
5. Replace lower heat shield by sliding it under control panel then tilt it up. Fasten it in place with two screws.
6. Connect electrical power source.